

OVEN PARTS 27" BUILT-IN ELECTRIC




Illus.	Part		lllus.	Part		lllus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3191638	French Use & Care Guide (Oven) English French Use & Care Guide (Microwave) English	5 6 7 8 9 10 11 12 13 14 15 16 17 18	4455864 4455605 4452158 4452165 4452368 4452166 8300791 4455611 4455381 3196176 4449040 4452152	Spacer, Foam Top Chassis Hinge Receiver Left Hand Right Hand Tube, Vent Lens,Light Oven Light Assy Bulb,Light Bracket, Combo Frame, Front Gasket, Door Screw	30 32 33 34 37 43 49 50 51	8300154 9760676 4451666 9759243 4455529 4448933 4451747 8302937 8302938 8302939 8302940 8303503	Bracket, Support Insulation, Bottom Vent Deflector, Vent Vent, Center Thermostat (TOD) (Temp.) SPST Base, Chassis Retainer, Gasket Cover, Back Trim, Bottom Black Model White Model Biscuit Model S.Steel Vent, Control Chassis, Back
3 4	8302929 8302931 8303217 8302928 8302930 8302932 8303218 8281236	RH Black RH White RH Biscuit RH S.Steel LH Black LH White LH Biscuit LH S.Steel	21 22 23 25 26 27 29	8303117 8303118 4449154 4450038 4455641	Rail, Side Right Side Left Side Screw Screw Side, Chassis (R.H. & L.H.) Back, Chassis Liner, Oven (Not serviceable)		FOLLOW NOT ILL ILATION 4449315	VING PARTS USTRATED Insulation, Wrap Insulation, Back

CONTROL PANEL PARTS



Illus. No.	Part No.	DESCRIPTION
1 2	8303819 8303948	Assy, Control Assy, Switch Black & Steel Mdl
3 4 5	8303949 8303950	White Model Biscuit Model Control, Bracket
6	8302845 8302846 4451592	Black Model White Model Biscuit Model Filter
7 8 9 10	4449745 4449809	


OVEN DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus.	Part No.	DESCRIPTION
1 2		Door Liner Hinge, Door R.Hand (Clear)	13		Door Handle Black Model White Model	17 18	3400832 8303299	Screw Assy.,Door Glass Black Model
3 4	9760576 4449253	L.Hand (Clear) Glass, Inner Insulation, Door	14	8302812 8303163	Biscuit Model S.Steel		8303305 8303309	White Model Biscuit Model S.Steel Model
5 6 7	4457131 4449809	Retainer, Glass	14 15 16	9759229	Bracket, Handle Bracket(2nd Glass) Bracket(3rd Glass)	19 22	4457102	Shield, Heat Shield, Heat (Btm)

LATCH PARTS

For Models:GMC275PRB01, GMC275PRQ01, GMC275PRT01, GMC275PRS01 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow Vent-Top
3	4455177	Elbow Vent-Bottom
4	4449040	Screw
9	4450407	Baffle, Rear
10	4449809	Screw
11	9759525	Latch, Motorized
16	4452003	Blower
21	4451758	Seal, Foam
22	4455191	Plate, Blower


PRODUCT SAFETY INFORMATION


ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO $-\,\text{IT}-\,\text{YOURSELF}$ REPAIRS OF MICROWAVE OVENS.


The U.S. Consumer Product Saftey Commission warns against do—it—yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

INTERNAL OVEN PARTS








Illus. No.	Part No.	DESCRIPTION
1	4456103	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Flement Bake

CABINET AND STIRRER PARTS

CABINET AND STIRRER PARTS


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 3 4 5 11 12 13 14 15 16 17 19 20 21 25 26	4375037 4375038 4375314 4375315 4375260 4375316 4375322 4375317 4375264 4375248 4375318 4375319 4375320 4375020	Air Duct, Magnetron Damper Duct, Inlet Insulation, Switch Fan Wheel Duct, Air Block, Slide Cover Plate, Upper Lens, Lamp	27 28 29 30 31 34 35 36 37 38 39 40 41	4375279 4375079 4375286 4375323 4375324 4451008 4375327 4375328 4375329 4375331 4375333	Block, Fuse Motor, Blower Thermostat Thermostat Transformer Hinge, Door Left Right Torsion Spring Bracket, Hinge Left Right	42 43 44 45 46 47 48 49 50 51 52 53 54 55 56	4375338 4375340 4375341 4375342 4455915 4375344 4375345 4375346 4375347 4375348 4375350	Right Isolation Plate Cover Plate Plate, Door Inner Frame Side Plate Right Left Turntable Ring Assembly Shaft Switch Motor, Turntable Lamp Rectifier

MICROWAVE DOOR PARTS




llus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
9 10 11 13 14 15	8303555 8303810 4449141 4449142 4449809	Glass, Middle Frame, Door Nameplate Bracket, Mounting Right Side Left Side Screw Filler, Side	16	8302811 8302812 8303163 8303262 8303270 8303246	Handle, Door Black Model White Model Biscuit Model S.Steel Model Glass, Outer Black Model White Model Black Stainless Biscuit Model	18 24 25	4449809 8303168 4451040	Bracket, Handle

MICROWAVE COMPARTMENT PARTS



Illus. No.	Part No.	DESCRIPTION
5		Support Rails
	4452551	Right Side
	4452552	Left Side
6	4449809	Screw
7	4452547	Rear Channel

TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4450377	Cover, Top	10	4454976	Fuse	17	4448664	Clamp
2		Baffle, Blower	1 11		Block, Terminal	18		Cover, Top Vent
3	4450920	Blower	12		Side, Combo	19		Transformer,
4	4450027	Bracket, Duct	14		Side, Control Top			Control
5	6610122	Transformer,	''	4451597		20	8302143	Suppressor
		(Lights)		4451598	0	21		Plate, Cover
6	8303844	Exhaust Duct	15	4452244	Back, Control	22	4449809	
7	4451789	Plate, Mounting	16		Cover, Top Rear	23	4449154	Screw
8	4449964	Grommet			, ,	24	3400080	Screw
9	4454949	Holder, Fuse						

OPTIONAL PARTS

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
PAINT, TOUCH-UP (1/2oz.) 72017 White 261869 Cord Brown 72032 Black PAINT, SPRAY	SPLICING WIRES25FT. LENGTH 242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga.	FOLLOWING PARTS NOT ILLUSTRATED 4378950 Filler Kit (BL) 4378951 Filler Kit (WH) 814381 Kit, Hinge Pin 4448950 Screw, Installation
350930 White 261900 Citrine White 830864 Black ADHESIVE 591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)	150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242829 Wire (12 Ga. 150 c Red) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242826 Wire (14 Ga. 150 c White) 242827 Wire (14 Ga. 150 c Yellow) 242832 Wire (14 Ga. 200 c Yellow)	WIRING HARNESS PARTS 8301909 Harness, Latch 8304156 Harness, Main 8304200 Harness, Filter 4452400 Lead, Ground Strap 4450831 Ground (M/W) 4450800 Screw 4449809 Screw 4450950 Conduit, Combo 313438 Clip, Harness 4452222 Spacer, Harness 4454835 Tie, Cable